



P.O. BOX 501  
CONCORD NH 03302-0501  
509 ROUTE 3A  
BOW NH 03304  
800-258-3708  
603-225-6684  
FAX 603-225-8497  
www.pitco.com

## **SMOKER BOX USER'S GUIDE**

1. Place one (I)-smoker box in each water tub. Using more than one smoker box per water tub will void the warranty.
2. Use mesquite wood chips or small logs. Soak the wood chips or logs overnight if possible, (minimum of 30 minutes). The radiant heat from above will ignite the wood. Remember this feature is designed to add flavor and is not the primary fuel to cook the food. Do not overload the smoker box. Logs or chips should be a few inches back from the front edge of the smoker box. Do not put more than one log in at a time into each smoker box.
3. Fill the water tub by sliding it out two or three inches only. When filled, slide it back under the burners. Fill with approximately 2 inches of water and periodically fill as it evaporates. Slide water tubs slowly being careful not to splash hot water onto you.
4. Remove old ashes prior to each day's use of the smoker box. Do not attempt to remove ashes or water tubs from a hot unit. Do not remove ashes if there are still glowing embers or hot coals.



5. Always wear protective clothing when working with the smoker box unit. Metal surfaces become very hot and may cause burns if protective clothing is not worn.